

SHEET NUMBER 28057 VERTICAL BORER BRAND SCHIESS.-



CORPORATE MACHINERY BROKERS

PO BOX 1043 KENSINGTON GARDENS S.A. 5068

TEL. 042 8832 423

TEL.08-84310430

E. marketing@machineryshowroom.net

WEB. www.machineryshowroom.net

ADD GST TO ALL PRICES

ALL SALES ARE SUBJECT TO OUR ANNEXURE 'A' CONDITIONS OF SALE.

SHEET NUMBERS 28055- 28057- 28058- VERTICAL BORERS.

APPLICATIONS INCLUDE REPAIRS OF SLEW RINGS [DEFINED AS- TO TURN OR TWIST SOMETHING ON ITS OWN AXIS WITHOUT MOVING FROM ITS PLACE—TO SWING AROUND]. FOR PRODUCTS VIZ.....

AERIAL LIFTS—AMUSEMENT PARK RIDE MACHINES—BEARINGS--
BOOM CRANES-- BUCKET WHEEL RECLAIMERS—BUNCHERS—
COMMUNICATION /RADAR ANTENNAE—CONCRETER PUMPS—
DEMOLITION ROBOTS—LARGE ELECTRIC MOTORS—
EXCAVATORS/HYDRAULIC—FELLERS—FOUNDRY CASTINGS--
FORWARDERS—GENERATORS—GUN MOUNTS—MOBILE CRANES—
LAUNCHING MOUNTS—PUMPS—RECYCLING MACHINES— SHIP
CRANES—SHIP LOADERS—SINGLE BUOY MOUNTING SYSTEMS—SOLAR
ARRAY SLEWS—TANK TURRETS-- TOWER CRANES—TUNNEL BORING
MACHINES—TURNTABLES—VALVES—VACUUM UNLOADERS—WELD
MANIPULATORS—WIND TURBINES – WIRE COILERS—ETC ETC.

PAGE 6 SHOW/RM MS 8 LINE J5

CORPORATE MACHINERY BROKERS

PO BOX 1043 KENSINGTON GARDENS, SA, 5068

Tel: 042 8832 423

Tel: 08 8431 0430

Email: marketing@machineryshowroom.net

WEBS: www.machinesforsale.com.au

www.machineryshowroom.net

ADD GST TO ALL PRICES

ALL SALES ARE SUBJECT TO OUR ANNEXURE 'A' CONDITIONS OF SALE



SHEET NUMBER 28057 VERTICAL BORER AND TURNING MILL. BRAND K.SCHEISS----TABLE DIAMETER 2500M

DOUBLE COLUMN HEADS. W/- GUARDS.

SPECIFICATIONS:

Head Swivel.	-	Vertical Fine Adjustment Manual.	-	Clamping of Ram.
Vertical Hand Traverse.	-	Feed Change.	-	Horizontal Fine Adjustment.
Bridge Lube Pump.	-	Horizontal Hand Movement.	-	Main Drive Inching Speed Change Stop/ Start.
.				Release Clamp.Raise /Lower.
L.H Cross Rail Head.	-	Rapid Traverse Feed.	-	
Cross Rail Traverse				
Raise / Lower.	-	Tracer Control Panel.	-	Manual Clamping of Slide.
Clamping of Ram .	-	Swivelling of Head.	-	Vertical Fine Adjustment.
Clamping of Ram [Manual].		Horizontal Fine Adjustment.	-	Vertical Hand Traverse.
Feed Change.	-	Horizontal Hand Movement.	-	Main Drive Inching Speed.
Change Stop / Start.	-	RH Cross –Rail Head Rapid.	-	Traverse Feed.
Side Head Rapid				
Traverse Feed.	-	Manual Clamping of Slide.	-	Feed Change.
Horizontal				
Hand Movement.	-	Vertical Hand Movement.	-	Oil Flow Indicator.
Setting of Table Speed.-				

PAGE 6 SHOW/RM

MS 8

LINE J5

CORPORATE MACHINERY BROKERS

PO BOX 1043 KENSINGTON GARDENS, SA, 5068

Tel: 042 8832 423

Tel: 08 8431 0430

Email: marketing@machineryshowroom.net

WEBS: www.machinesforsale.com.au

www.machineryshowroom.net

ADD GST TO ALL PRICES

ALL SALES ARE SUBJECT TO OUR ANNEXURE 'A' CONDITIONS OF SALE